

Tips

To install – Loosen strap or remove it from the adjuster.

- Headpan should rise approximately ¼” from front to back.
- Strap should be pulled tightly, removing all slack. Be sure to pull strap under the headpan, also.
- Strap should be secured in the adjuster.

When reclined, back of chair should be close to, but not touching, the bottom of the headpan.

Towel should be draped around the client’s shoulders, not the neck.

Client should scoot back completely in chair so head rests comfortably.

Wash as usual; hands will be above HeadsUp®. To rinse:

- Hold nozzle close to head, at about a 45° angle.
- Point nozzle to the side of the shampoo bowl, not the front.
- Sweep water away from the neck with free hand.
- Turn head side to side to get to neck and part of head laying on headpan.
- Lift head to access the occipital region of the head.

If client gets wet, lower HeadsUp® slightly.

For perms, lower HeadsUp® slightly.

- Rinse back panel of rods/rollers by lifting and turning head.
- Move head gently because hair covered with perm solution is in a weakened state.

Caution: *For the safety of your clients, read, understand, and follow all instructions. Carefully observe all warnings and safeguards. After installation, try HeadsUp® yourself to make sure it is comfortable and installed properly.*